
Wilbur Curtis Co., Inc.

# ALPHA AUTOMATIC COFFEE BREWERS

SERVICE MANUAL

INCLUDES THE FOLLOWING UNITS:

- ALPHA 3X ALPHA 3XR ALPHA 3XL
  - ALPHA 2X ALPHA 1X ALPHA 6X



| Table of Contents                     |
|---------------------------------------|
| Setup 1                               |
| Coffee Requirements 1                 |
| Coffee Brewing 2                      |
| Maintenance & Cleaning 3              |
| Trouble Shooting 4 - 5                |
| Illustrated Parts, Alpha 3X 6 - 7     |
| Parts List Alpha 3X 8 - 9             |
| Parts List Alpha 3XR, 3XL, 2X, 6X 9   |
| Illustrated Parts, Alpha 3XR & 3XL 10 |
| Illustrated Parts, Alpha 2X 11        |
| Illustrated Parts, Alpha 6X 11        |
| Wiring Diagram, Alpha 3X, 3XR, 3XL 12 |
| Wiring Diagram, Alpha 2X 13           |
| Wiring Diagram, Alpha 1X 14           |
| Warranty Back Cover                   |
|                                       |

#### Carton Contents

| Qty | Item                           | Part N <sup>o</sup> |
|-----|--------------------------------|---------------------|
| 1   | Automatic Coffee Brewer        | Alpha               |
| 1   | Brewcone                       | WC-3621             |
| 25  | Paper Filters                  | CR-10               |
| 1   | Elbow Fitting, 3/8 X 1/4 Flare | WC-2401             |



#### WILBUR CURTIS CO., INC.

6913 Acco St., Montebello, CA 90640-5403 USA

◆ Technical Support Phone: 800/995-0417 (M-F5:30A - 4:00P PST) ◆ E-Mail: techsupport@wilburcurtis.com

Web Site: www.wilburcurtis.com

## <u>ALPHA X</u>

The Alpha X series of automatic coffee brewers require installation to be in compliance with all local water and electrical power codes. The Alpha is designed to brew 12 cups at a time. The Alpha 3X, 3XL and 3XR have three warmer plates that allow up to three decanters to be kept at serving temperature. The hot water faucet lets you draw hot water for tea, instant soups, chocolate drinks or cup meals - even during brew cycle.




Figure 1. Alpha Brewing System, Basic Components.

## **SET-UP INSTRUCTIONS**

1. WATER CONNECTION: A 3/8" NPT x 1/4" flare elbow fitting is supplied with this brewer for the water line connection. Use 1/4" copper tubing and flare nut to hook up your water source behind the machine. It is important to use a good water filter in the system before water enters the Alpha brewer.

**CAUTION**: Do not connect this brewer to hot water line. Inlet valve is not rated for hot water! Do not connect to water softener system.

- 2. Remove the top cover and lid from the heating tank. By hand, fill heating tank with water until heating element is submerged.
- 3. Locate the thermostat (see figure 1). Twist the thermostat stem clockwise as far as it will go.
- 4. Replace the heating tank lid and top cover.
- 5. Plug the power cord into a 115 VAC electrical outlet.
- 6. Turn on power at the *ON/OFF* power switch (front panel). At this time, if the heating tank was not completely filled, the automatic liquid level control will refill the tank.
- 7. Allow about fifteen minutes for the water in the heating tank to come up to proper temperature. The *READY TO BREW* light will turn on when the initial warm-up has completed. The unit is now ready to brew. Because water expands when heated, there may be a slight overflow discharge at this time.
- 8. Although this brewer has been thoroughly tested and cleaned at the factory, we suggest that you run several brewcycles of just hot water to flush the water lines of any air that may affect brew volume.

#### **COFFEE REQUIREMENTS**

The Alpha coffee brewer will produce excellent results using most grades of coffee available from your coffee distributor. Coffee suppliers can provide coffee in convenient pre-measured envelopes.

The Alpha coffee brewer is designed for *ground* coffee; freeze dried or liquid coffee products will not work.

The Wilbur Curtis Company manufactures bulk coffee dispensers (Models MCD-7 or MCD-7G) that consistently dispense ground coffee in selected amounts.




Figure 2. MCD-7G Coffee Dispenser

[2]

## COFFEE BREWING

- 1. Place a paper filter into the brew cone. Pour ground coffee into the filter.
- 2. Slide the brew cone into place. When pushed in against the stop, the brewcone fits into the slide rails and centers it under the sprayhead.
- 3. Place a clean coffee decanter on the warmer plate.


4. To start brewing, push in the momentary brew switch, located on the front panel. The brew cycle will take approximately three minutes to complete.

5. The warmer plates keep the coffee at serving temperature. To activate the warmers, push the desired warmer switch, located on the front panel.

## WARNING TO HELP AVOID PERSONAL INJURY:

- I FOLLOW ALL BREWING AND WARMING INSTRUCTIONS.
- I HOT COFFEE! ALLOW BREWCONE TO FINISH DRIPPING.
- USE ONLY CURTIS APPROVED ACCESSORIES.







### MAINTENANCE & CLEANING OF BREWER

Regular and preventive maintenance is essential in keeping your Alpha system looking and working like new.

**CAUTION** When cleaning your Alpha System, do not use cleansers, bleach liquids, powders or any other substance that contains chlorine. These products promote corrosion and will pit the stainless steel. USE OF THESE PRODUCTS WILL VOID WARRANTY.

#### PREVENTIVE MAINTENANCE

- 1. Remove the sprayhead from the brewer and clean it once a week or more often in heavy lime areas.
- 2. Clean the faucet seat cup and replace it if cracked or leaking.
- 3. The inside of the heating tank should be de-limed at least every six months and more often in areas with especially hard water.

#### CLEANING

Using a daily routine of cleaning the external parts of the Alpha brewing system should maintain its new appearance and better tasting coffee.

- 1. Wipe off any spills, dust or debris from the exterior surfaces.
- 2. Clean the outside of the brewer with stainless steel polish. Coarser agents may scratch the machine.
- 3. Slide out brew cone. Rinse thoroughly with clean water.
- 4. Remove the sprayhead and clean. Clean around the dome area, wiping with a non-toxic cleaner.
- 5. Clean the brew cone rails with a damp cloth or brush.
- 6. Dry thoroughly with a clean cloth.

## **TROUBLE SHOOTING**

## ANY SERVICE DONE ON THIS UNIT MUST BE PERFORMED BY A QUALIFIED SERVICE TECHNICIAN.

PROBLEM: Water does not flow into heating tank...

| POSSIBLE CAUSE                                 | SOLUTION  |
|--|---|
| Water line turned off or water filter clogged. | Disconnect the water line and test for water flow.  |
| Coil on Water Inlet Valve has burnt<br>out.    | Turn machine off. Disconnect wires from water inlet coil terminals and connect a power cord to the terminals. Plug into a 115V outlet to verify that water flows through when plugged in and stops when cord is disconnected. If the valve does not respond to this test, valve is defective. Replace valve or coil.                          |
| Grounded Water Level Probe.                    | When water in the heating tank is below the probe tip, the<br>tank should be refilling. Pull wire off the probe terminal. If<br>water starts flowing into the tank, probe may be grounded.<br>Clean or replace probe.<br>To reduce the recurrence of grounding, tightly wrap probe<br>with Teflon tape to 1/8" from tip.                      |
| Defective Liquid Level Control (LLC)<br>board. | Remove ORANGE wire from probe terminal. Do not allow<br>wire to touch any electrical parts. Test voltage at terminals<br>of Water Inlet Coil. This should read 110 to 220 Volts. If<br>there is no voltage, go to LLC Board. Check board for loose<br>connections or a bad ground. If this is okay, board is<br>defective. Replace LLC Board. |

#### PROBLEM: Water is overflowing from the heating tank

| POSSIBLE CAUSE   | SOLUTION   |
|--|--|
| Defective Water Inlet Valve.                             | Turn power off. Observe water level in tank. If water continues to fill tank, the valve may need cleaning or you may have a defective valve. Clean out or replace valve.   |
| Lime deposits on Probe.                                  | Pull wire off from probe terminal. Touch the metal side of water tank with connector end of wire. If water stops flowing, probe needs cleaning or replacement.   |
| Loose or ungrounded Liquid Level<br>Control (LLC) board. | Liquid Level Control board must be securely grounded to it's<br>mounting bracket. Check for loose connections. Make sure<br>there is no voltage present at the inlet valve terminals. If<br>voltage is present, replace LLC board. |

PROBLEM: water in tank does not get hot...

| POSSIBLE CAUSE              | SOLUTION   |
|-----------------------------|--|
| Thermostat turned off.      | Check the thermostat to make sure stem is turned all the way to the right.   |
| Burned out Heating Element. | If thermostat is on (closed) you should read 110/120 volts at the element terminals. Voltage present at these points but no heat, indicates the element is burned out. Replace it. |

#### PROBLEM: Water does not spray over coffee...

| POSSIBLE CAUSE            | SOLUTION   |
|---------------------------|--|
| Clogged Spray Head        | Remove the spray head from the brewer and inspect for obstructions. Clean and reinstall.   |
| No water in Heating Tank. | Remove tank lid. Determine if there is water in the tank. Follow instructions on page 3, <i>Problem: Water does not flow into Heating Tank</i> .   |
| Defective Brew Switch.    | Check the brew switch for continuity between terminals <b>1</b> (white wire) and <b>2</b> (blue wire). While pressing the switch. If there is no continuity or if you have to push the switch three or four times to read any continuity. Replace the brew switch.                       |
| Defective Timer.          | When the timer is activated by the Brew Switch you should read 110 to 120 volts across terminals <b>6</b> and <b>A</b> of the timer. The RED wire on terminal <b>6</b> supplies power to open the Dump Valve. If you can't read any voltage across the two terminals, replace the timer. |
| Burned out Dump Valve.    | Check the dump valve coil using a volt meter on the dump valve terminals. If it is showing 110 to 120 volts but valve does not actuate, valve is defective; replace the valve.   |




Figure 3. Illustrated Parts List, Main View (Alpha 3X Shown).




Figure 4. Illustrated Parts List, Detail Bubbles (Alpha 3X Shown).

## **ALPHA Parts List**

| NUMBER | PART<br>NUMBER | DESCRIPTION                                      |
|--------|----------------|--|
| 1      | WC-38310       | LABEL, "CAREFUL HOT SURFACE"                     |
| 2      | WC-6205        | COVER, TOP WARMER DECK                           |
| 3      | WC- 517        | THERMOSTAT                                       |
| 4      | WC-4505        | SCREW, 8-32 x 1/2 PHILLIPS                       |
| 5      | WC-2977        | FITTING, SPRAYHEAD                               |
| 6      | WC-4320        | O' RING  |
| 7      | WC-2922        | SLEEVE, BY-PASS, INCL. SCREW                     |
| 8      | WC- 604        | TIMER, BREW                                      |
| 9      | WC-4436        | SCREW, 4x3/8 PHIL PAN HEAD                       |
| 10     | WC-3958        | LABEL, TOP SWITCH PANEL, ALPHA 3                 |
| 11     | WC- 130        | SWITCH, ON/OFF, WHITE                            |
| 12     | WC- 129        | SWITCH, WARMER, RED                              |
| 13     | WC- 128        | SWITCH, BREW, GREEN                              |
| 14     | WC- 202        | LIGHT, BREW READY, 120V                          |
| 15     | WC-1809        | FAUCET, HOT WATER                                |
| 16     | WC-1806        | SEAT CUP, SILICONE                               |
| 17     | WC-5477        | COVER, FRONT                                     |
| 18     | WC-4213        | LOCK NUT 5/8" BRASS                              |
| 19     | WC-2936        | SPRAYHEAD, RED                                   |
| 20     | WC-1411        | BUSHING, 5/8" SNAP-IN                            |
| 21     | WC-5819        | COVER, BOTTOM                                    |
| 22     | WC-3621        | BREW CONE, UNIVERSAL (STANDARD)                  |
| 23     | CR-10          | FILTER PAPER, 12 CUP (BOX OF 1,000)              |
| 24     | WC-3503        | FOOT, RUBBER, 3/8 - 16 STUD                      |
| 25     | WC-1408        | CORD GRIP, STRAIN RELIEF, 7/8"                   |
| 26     | WC-1200        | POWER CORD, 120V                                 |
| 27     | WC-2401        | ELBOW, 1/4 x 3/8, FLARE                          |
| 28     | WC-4616        | SCREW, 1/4-20x½ PHILLIPS PAN HEAD SS             |
| 29     | WC- 826L       | VALVE, INLET 1 GPM, 120V 10W                     |
| 30     | WC- 608        | LIQUID LEVEL CONTROL BOARD                       |
| 31     | WC-4380        | SHOCK GUARD, LLC                                 |
| 32     | WC-4329        | LOCK WASHER, EXTERNAL #8                         |
| 33     | WC-4525        | SCREW, 8-32x¼ PHILLIPS TRUSS HD SS               |
| 34     | WC-6207        | UPPER WARMER DECK UNIT                           |
| 35     | WC-37102       | KIT, WARMER ELEMENT 100W 120V                    |
| 37     | WC-4201        | NUT, KEP, 8-32, ZINC                             |
| 38     | WC-6732        | STRAP FOR WARMER PLATE                           |
| 39     | WC-6234        | WARMER PLATE ASSEMBLY (ITEM № 35 THRU 38)        |
| 40     | WC-54031       | HEATING TANK WITH FITTINGS                       |
| 41     | WC-54032       | TANK, ASSY HEATING W/FITTINGS & HTNG ELMNTS 120V |
| 43     | WC-43014       | GASKET, HEATING TANK                             |
| 44     | WC-4543        | SCREW, 8-32 x 1" SLOTTED HEX SS                  |
| 45     | WC-4211        | NUT, 3/8" JAM                                    |
| 46     | WC-4212        | NUT, 5/8" JAM                                    |
| 48     | WC-29015       | FITTING, BARBED OVERFLOW                         |
| 49     | WC-29009       | FITTING, BARBED INLET                            |

## **ALPHA 3X Parts List**

| INDEX<br>NUMBER | PART<br>NUMBER | DESCRIPTION                             |
|-----------------|----------------|---|
| 50              | WC-5502        | PROBE, WATER LEVEL                      |
| 51              | WC-2938        | FITTING, 1/8" HEX FOR WATER LEVEL PROBE |
| 52              | WC-4394        | SHOCK GUARD FOR HEATING ELEMENT         |
| 53              | WC-4306        | WASHER, 9/16" I.D. TEFLON               |
| 54              | WC- 917-04     | HEATING ELEMENT, 120V, 1450W            |
| 55              | WC-5409        | CLIP, THERMOSTAT CAPILLARY              |
| 56              | WC-43058       | PLUG, TANK DRAIN PP RED                 |
| 57              | WC-3685        | INSULATION, WRAP ALPHA                  |
| 58              | WC-5310        | TUBING, SILICONE, 5/16" I.D             |
| 59              | WC-3765L       | KIT, INLET VALVE REPAIR                 |
| 60              | WC- 829        | WASHER, FLOW                            |
| 61              | WC- 889        | VALVE, DUMP LEFT 120V 12W               |
| 62              | WC- 411        | COIL FOR DUMP VALVE (WC-821)            |
| 63              | WC-3763        | KIT, DUMP VALVE FOR WC889               |

## ALPHA 3XR, 3XL, 2X, 6X. PAGE 9, 10, 11.

| 64<br>65<br>66<br>67<br>68<br>70<br>71 | WC-6206<br>WC-5820<br>WC-39096<br>WC-6224<br>WC-39039<br>WC-6642<br>WC-6666 | COVER, ALPHA 3XR & 3XL TOP<br>COVER, ALPHA 3XR & 3XL BOTTOM<br>LABEL, ALPHA 3XR & 3XL SWITCH PANEL<br>COVER, ALPHA 2X TOP<br>LABEL, ALPHA 2X SWITCH PANEL<br>COVER, ALPHA 6X TOP<br>COVER, ALPHA 6X FRONT |
|--|---|---|
| _                                      | WC-6642<br>WC-6666  | COVER, ALPHA 6X TOP   |
| 72                                     | WC-5895   | COVER, ALPHA 6X BOTTOM  |




Figure 5. Illustrated Parts, Alpha 3XR & 3XL.




Figure 6. Illustrated Parts, Alpha 2X.




Figure 8. Illustrated Parts, Alpha 6X.




Figure 9. Alpha-3X -10, Wiring Diagram





Figure 10. Alpha-2X -10, Wiring Diagram

#### [ 13 ]



THIS PAGE INTENTIONALLY LEFT BLANK

#### Product Warranty Information

The Wilbur Curtis Company certifies that its products are free from defects in material and workmanship under normal use. The following limited warranties and conditions apply:

- 3 Years, Parts and Labor, from Original Date of Purchase on digital control boards.
  - 2 Years, Parts, from Original Date of Purchase on all other electrical components, fittings and tubing.
    - 1 Year, Labor, from Original Date of Purchase on all electrical components, fittings and tubing.

Additionally, the Wilbur Curtis Company warrants its Grinding Burrs for Forty (40) months from date of purchase or 40,000 pounds of coffee, whichever comes first. Stainless Steel components are warranted for two (2) years from date of purchase against leaking or pitting and replacement parts are warranted for ninety (90) days from date of purchase or for the remainder of the limited warranty period of the equipment in which the component is installed.

All in-warranty service calls must have prior authorization. For Authorization, call the Technical Support Department at 1-800-995-0417. Effective date of this policy is April 1, 2003.

Additional conditions may apply. Go to <u>www.wilburcurtis.com</u> to view the full product warranty information.

#### **CONDITIONS & EXCEPTIONS**

The warranty covers original equipment at time of purchase only. The Wilbur Curtis Company, Inc., assumes no responsibility for substitute replacement parts installed on Curtis equipment that have not been purchased from the Wilbur Curtis Company, Inc. The Wilbur Curtis Company will not accept any responsibility if the following conditions are not met. The warranty does not cover and is void under the following circumstances:

- **1) Improper operation of equipment:** The equipment must be used for its designed and intended purpose and function.
- 2) Improper installation of equipment: This equipment must be installed by a professional technician and must comply with all local electrical, mechanical and plumbing codes.
- **3) Improper voltage:** Equipment must be installed at the voltage stated on the serial plate supplied with this equipment.
- 4) Improper water supply: This includes, but is not limited to, excessive or low water pressure, and inadequate or fluctuating water flow rate.
- 5) Adjustments and cleaning: The resetting of safety thermostats and circuit breakers, programming and temperature adjustments are the responsibility of the equipment owner. The owner is responsible for proper cleaning and regular maintenance of this equipment.
- 6) Damaged in transit: Equipment damaged in transit is the responsibility of the freight company and a claim should be made with the carrier.
- 7) Abuse or neglect (including failure to periodically clean or remove lime accumulations): Manufacturer is not responsible for variation in equipment operation due to excessive lime or local water conditions. The equipment must be maintained according to the manufacturer's recommendations.
- 8) Replacement of items subject to normal use and wear: This shall include, but is not limited to, light bulbs, shear disks, "0" rings, gaskets, silicone tube, canister assemblies, whipper chambers and plates, mixing bowls, agitation assemblies and whipper propellers.
- 9) Repairs and/or Replacements are subject to our decision that the workmanship or parts were faulty and the defects showed up under normal use. All labor shall be performed during regular working hours. Overtime charges are the responsibility of the owner. Charges incurred by delays, waiting time, or operating restrictions that hinder the service technician's ability to perform service is the responsibility of the owner. This includes institutional and correctional facilities. The Wilbur Curtis Company will allow up to 100 miles, round trip, per inwarranty service call.

**RETURN MERCHANDISE AUTHORIZATION:** All claims under this warranty must be submitted to the Wilbur Curtis Company Technical Support Department prior to performing any repair work or return of this equipment to the factory. All returned equipment must be repackaged properly in the original carton. No units will be accepted if they are damaged in transit due to improper packaging. NO UNITS OR PARTS WILL BE ACCEPTED WITHOUT A RETURN **MERCHANDISE AUTHORIZATION (RMA). RMA NUMBER MUST BE MARKED ON THE CARTON OR SHIPPING LABEL.** All in-warranty service calls must be performed by an authorized service agent. Call the Wilbur Curtis Technical Support Department to find an agent near you.

urtis